

6. Do NOT attempt to disassemble, repair or modify the device.

with mounting clip

### p without mounting clip







46mm

Product type	Wi-Fi Curtain Module
Voltage	100-240V AC 50/60Hz
Current	3A
WiFi frequency	2.4GHz - 2.4835GHz WIFI
Operation temp.	-10°C -+40°C
Case temp.	Tc: +80°C (Max.)
Operation range	≤ 200 m
Dims (WxDxH)	46x46x18mm(without clip)
IP rating	IP20
Warranty	2 years

EMC Standard (EMC) EN 303 328 V2.1.1 (2016-11), EN 301489-17 V3.1.1 (2017-02), EN 301489-17 V3.1.1 (2017-02), EN 62311: 2008, EN 61000-6-1:2007, EN 61000-6-3:2007+A1:2011 Safety Standard (LVD) IEC 60669-2-1:2002/AMD1:2008/ AMD2:2015, IEC 60669-1:1998/ AMD1:1999/AMD2:2006, EN 60669-2-1:2004+A1: 2009+ A2:2010, EN 60669-21:2018 RoHS Standard (RoHS)

2011/65/EU, (EU) 2015/863 Radio Equipment (RED)

Radio Equipment (RED) ETSI EN 300 328 V2.1.1 (2016-11)



Wiring Instructions and Diagrams

- 1.Turn off the power supply before carrying out any electrical installation work.
- 2.Connect wires according to the wiring diagram.

3.Insert the module into the junction box.

4.Connect the power supply and followCurtain module configuration instructions.

Notes: Take your smartphone close to the Curtain module when you're configuring, and make sure you have min. 50% Wi-Fi signal. Global international operation Whenever & Wherever You are, All-in-one Mobile App



#### Inhouse local operation



### FAQ

Q1: What should I do if I can't configure the Curtain module?

- a. Please check whether device is powered on.
  b. Make sure your mobile and Curtain module
- b. Make sure your mobile and Curtain module are under the same 2.4 Ghz WIFI network.
- c. Whether it's in good internet conditions.
- d. Make sure the password entered in App is correct.
- e. Make sure the wiring is correct.

Q2: Which products can I control with the device? Curtain,shutter, blind.....

Q3: What happens if the WIFI goes off?

You can still control the device connected the Curtain module with your traditional curtain and once WIFI is active again the device connected to module will connect automatically to your WIFI network.

Q4: What should I do if I change the WIFI network or change the password?

You can connect the module to the WIFI network according to the App User Manual.

#### Q5: How do I reset the device?

- 1. Long press the reset key for about 10 seconds until the indicator light flash guickly.
- 2. Press the traditional switch for 10 times until the indicator light flash quickly.
- 3. Power on/off for 5 times until the indicator light flash quickly.

## MANUAL OVERRIDE

The Curtain module terminal reserves the access of manual override function for the end-user to switch on/off.

 If you have connected the wall push-button, check its work. Single pressing ofthe "down" button / "up" button, will cause that the roller shutters moves in the desired direction to the end position. If the electric shutter goes in the opposite direction to the expected,select "motor reversal" in the "More"option. When the electric shutter is moving up, pressing "up" button switches causes that the shutter will stop immediately: when the electric shutter is moving down, pressing "down" button switches causes that the shutter will stop immediately.

### Notes:

- 1) Both the adjustment on App and Curtain can overwrite each other, the last adjustment remains in memory.
- 2) The App control is synchronized with the manual switch.

## INSTALLATION

### ▲ Warnings:

1. Installation must be carried out by a qualified electrician in accordance with local regulations.

2. Keep the device out of reach of children.

# APP USER MANUAL



IOS APP / Android APP



Scan the QR code to download Tuya Smart App, or you can also search keyword "Tuya Smart" at App Store or Googleplay to download App.

